

# **EutroSORB®G**

# **Phosphorus Locking Technology**

For use in aquatic systems including lakes, reservoirs, rivers, ponds, lagoons, etc. to remove phosphorus and improve water quality.

## **KEEP OUT OF REACH OF CHILDREN**

Read Precautionary Statements, First Aid, Directions for Use and Storage and Disposal before use. Consult the Safety Data Sheet for additional information.

# **PRECAUTION STATEMENTS**

Avoid breathing dust. A proper-fitting mask is recommended to avoid respiratory irritation. Avoid contact with eyes and skin. Wear protective eyewear and chemical-resistant gloves when handling. Avoid ingestion.

	FIRST AID
If Inhaled	Move person to a dust free area.
	If person is not breathing, call 911 or an ambulance immediately.
	Call poison control center or doctor for further treatment advice.
If on Skin	Take off contaminated clothing.
or clothing	Rinse skin immediately with plenty of water for 15 to 20 minutes.
	Call a poison control center or doctor for treatment advice.
If in Eyes	Hold eyes open and rinse slowly and gently with water for 15 to 20 minutes.
	Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye.
	Call a poison control center or doctor for treatment advice.
If	Call a poison control center or doctor immediately for treatment advice.
Swallowed	Have person sip a glass of water if able to swallow.
	Do not induce vomiting unless told to do so by the poison control center or doctor.
	Do not give anything by mouth to an unconscious person.

treatment. In case of emergency endangering health or the environment involving this product call **INFOTRAC** at **1-800-535-5053**.

#### **DIRECTIONS FOR USE**

For best results, distribute uniformly over the surface of the waterbody, or the area targeted for application, as an aqueous slurry. Under certain conditions EutroSORB G may also be applied directly to the water based on management objectives and site conditions. For site specific rates, treatment recommendations, or applications to waters with hardness less than 50ppm, contact SePRO Corporation at 1-800-419-7779. Treatment with this product will not by itself make water potable. For applications in waters destined for use as drinking water, those waters must receive additional and separate potable water treatment.

## STORAGE AND DISPOSAL

Do not contaminate water, food, or feed by storage or disposal.

**Storage:** Store in original container and keep closed. Store in a dry place.

**Container Handling:** 

**Non-refillable Container (non-rigid, any size):** Do not reuse or refill this container. Completely empty bag into application equipment. Offer for recycling if available. If recycling is not available then dispose of empty bag in a sanitary landfill or by incineration, or if allowed by state and local authorities, by burning. If burned, stay out of smoke.

**Warranty Disclaimer:** SePRO Corporation warrants that this product conforms to the chemical description on the product label. Testing and research have also determined that this product is reasonably fit for the uses described on the product label. To the extent consistent with applicable law, SePRO Corporation makes no other express or implied warranty of fitness or merchantability, nor any other express or implied warranty and any such warranties are expressly disclaimed.

**Misuse:** To the extent consistent with applicable law, the buyer assumes responsibility for any adverse consequences if this product is not used according to its label directions. In no case shall SePRO Corporation be liable for any losses or damages resulting from the use, handling or application of this product in a manner inconsistent with its label.

For additional important labeling information regarding SePRO Corporation's Terms and Conditions of Use, Inherent Risks of Use and Limitation of Remedies, please visit http://seprolabels.com/terms or scan the image at the below.



EutroSORB is a registered trademark of SePRO Corporation Copyright ©2023 SePRO Corporation FPL20230201

SePRO Corporation 11550 North Meridian Street, Suite 600, Carmel, IN 46032, U.S.A.